

&tradition[®]



BELLEVUE AJ2

by Arne Jacobsen

USER INSTRUCTIONS

andtradition.com

Congratulations on choosing this Bellevue floor lamp, designed by Arne Jacobsen in 1929. We hope you will enjoy using this lamp. To ensure correct use please follow these instructions. If you have any questions or comments, please do not hesitate to contact us by mail on: **info@andtradition.com**


Description Of Parts:

- A - Lamp Shade
- B - Adjustable goose-neck
- C - Screw
- D - Height adjustable pillar
- E - 3 meter cord with foot-switch

Please read these instructions carefully and retain them for future reference to ensure that the lamp is used correctly. For your own safety, please study each step of this instruction manual first. &Tradition are not responsible for any faults or damages caused by not following these instructions correctly. Do not modify this lamp in any way.

Installation Suggestions:

The Bellevue AJ2 floor lamp can be used as a stand alone lighting source or in combination with the other lamps in the Bellevue series. Place it next to a sofa, armchair, credenza or bedside table. The lamp can also be used in combination with the rest of the &Tradition collection. Visit our website for more inspiration: www.andtradition.com



Safety Precautions:

- Dispose of plastic bag from packaging and do not allow children to play with it.
- The lamp is only intended for interior use.
- Lamp shade gets hot after prolonged use.
- Do not place the cable in reach of small children or anywhere there is a risk of falling over it.

Cleaning Instructions:

- Wipe surface of lamp shade with a soft, damp sponge or cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, turpentine, household glass cleaner or cellulose thinners.
- Only wipe the inside of the shade with a soft, damp cloth or feather duster.

01.



Follow these steps when adjusting the height of the shade. Be sure not to over extend the lamp height beyond the maximum height of the pillar.

To raise the shade:

1. Loosen the screw.
2. Pull the shade up to the desired height.
3. Tighten the screw.


To lower the shade:

1. Loosen the screw.
2. Lift the lamp by the pillar beneath the screw. This allows the cord to move freely.
3. Lower the shade to the desired height.
4. Tighten the screw.



02.


The lamp accepts standard screw mount bulbs:



Maximum 60 W.
Tungsten E27 bulb.




Maximum 12 W.
Low Energy E27
bulb.



03.

Use the flexible goose-neck to set the shade at a desired angle. It is best to set the angle before turning the lamp on as the shade gets hot when the lamp is in use for longer periods of time.



CE □ F IP20

& tradition[®]
COPENHAGEN

KONGEVEJEN 2. DK-3480 FREDENSBORG.

T. +45 39200233 F.+45 39200256

INFO@ANDTRADITION.com WWW.ANDTRADITION.COM